

Grandi Groomer Carpet Rake

Instructions for Assembly

Tools Needed: Crescent Wrench or Pliers 

1. Unfasten bolts from head attachment and align pole bracket behind head to screw ports with bracket bends facing toward the floor.
2. Hand tighten nuts to screws from back side as seen in 2a. Then use a crescent wrench to secure tightly.

2a.



For more info visit:
www.groomindustries.com